



OPERATING INSTRUCTIONS STYLE 538 CELLAR NOZZLE APPLICATOR

The following is intended to provide the basic instructions for operating a nozzle. Read and understand these operating instructions before use.

PRODUCT RATINGS:

Maximum Pressure: 200 psi/14 bar.

PRODUCT WARNINGS:

- WARNING:** Charge all lines slowly to facilitate a controlled water pressure build-up during start-up. Open and close slowly. Rapid opening will produce a sudden thrust. Rapid opening and closing can cause water hammer. Have enough firefighters on the line to safely control the reaction force created by the stream.
- WARNING:** At pressures below that indicated on the label, the nozzle will have reduced flow and reach. Be sure you have enough flow and pressure for the situation (See IFSTA and NFPA manuals for guidelines).
- WARNING:** Do not use the nozzle in portable hose holders.
- WARNING:** Ensure the nozzle is aimed in a direction that is safe, prior to opening the shutoff bale.
- WARNING:** Do not use the nozzle as a forcible entry tool. Doing so may damage it or make it inoperable.
- WARNING:** Ensure the thread on the nozzle swivel is matched to the thread on the hose connection.
- WARNING:** When operating at lower pressures the hose can kink more easily. A kink in the hose chokes off the flow, which may result in inadequate flow for the situation.

PRODUCT CAUTIONS:

- CAUTION:** If any tags or bands on the nozzle are worn or damaged and cannot be easily read, they should be replaced.
- CAUTION:** For use with fresh water or standard firefighting foams only. Not recommended for use with salt water. After use with foam or salt water, flush with fresh water.
- CAUTION:** For firefighter use only.
- CAUTION:** Do not overtighten the nozzle onto the hose connection.
- CAUTION:** The nozzle is configured for optimum performance. Do not alter in any manner.
- CAUTION:** Your nozzle should be inspected prior to and after each use, to ensure it is in good operating condition. Periodically, an unanticipated incident may occur where the nozzle is used in a manner that is inconsistent with standard operating practices and those listed in IFSTA. A partial list of potential misuses follows:
- Operating above maximum rated pressure and flow.
 - Not draining, and allowing water to freeze inside the nozzle.
 - Dropping the nozzle from a height where damage is incurred.
 - Prolonged exposure to temperatures above +130 degrees F, or below -25 degrees F.
 - Operating in a corrosive environment.
 - Other misuse that might be unique to your specific fire fighting environment.
- There are many "tell tale" signs that indicate nozzle repair is in order, such as
- Controls that are inoperable or difficult to operate.
 - Excessive wear.
 - Poor discharge performance.
 - Water leaks.

If any of the above situations are encountered, the nozzle should be taken out of service and repaired, plus tested by qualified nozzle technicians, prior to placing it back in service.

A. OPERATING INSTRUCTIONS

BALL SHUTOFF

- Open and close slowly.
- To open: Pull the handle toward the inlet.
- To close: Push the handle towards the outlet.

APPLICATOR

- Deploy legs
- Place nozzle through opening cut in floor
- Slowly open ball handle on ball valve

B. MAINTENANCE

- Under normal conditions, periodically flushing the nozzle with clean water and cleaning grit and dirt from around exterior moving parts will allow the nozzle to operate as designed.
- Over time the seats may need replaced. This can be accomplished by purchasing the appropriate Akron repair parts. Use Qualified maintenance mechanics or return the nozzle to Akron Brass for repair.
- Use low temp Lubriplate on metal parts and Parker O-Ring lubricant on O-Rings.



PHONE: 330.264.5678 or 800.228.1161 | FAX: 330.264.2944 or 800.531.7335 | www.akronbrass.com

REVISED: 8/08

WARRANTY AND DISCLAIMER: We warrant Akron Brass products for a period of five (5) years after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service.

We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; damage; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty.

© Premier Farnell Corporation. 2000 All rights reserved. No portion of this can be reproduced without the express written consent of Premier Farnell Corporation.

A Premier Farnell Company