

HARNESS WIRING		
COLOR	CABLE 1	CABLE 2
	(BOTTOM POS.)	(TOP POSITION)
RED	POWER	POWER(+12VDC)
	(+12VDC)	HAL.SCENE POS.8
GREEN	RANDOM FLASH MODE	GROUND
	(SWITCHED TO +12V)	HAL. SCENE POS. 5
BLACK	WIG-WAG MODE	POWER(+12VDC)
	(SWITCHED TO GND.)	HAL. SCENE POS.5
WHITE	GROUND	GROUND
		HAL. SCENE POS. 8

