



STYLE 5175 SELECTABLE GALLONAGE NOZZLE OPERATING INSTRUCTIONS

The following is intended to provide the basic instructions for operating a STYLE 5175 nozzle. Read and understand these operating instructions before use.

PRODUCT RATINGS

Flow: Style 5175	1000, 2000, 3000, & 4000 LPM at 7 bar 260, 525, 790, & 1050 GPM at 100 psi
Maximum Pressure:	200 psi/14 bar
Style 5175 Minimum Voltage at motor:	12 Volt Motor: 10 Volts at 15 amps 24 Volt Motor: 20 Volts at 7.5 amps
Style 5175 Maximum Motor Current Draw:	12 Volt Motor: 3 amps 24 Volt Motor: 1.5 amps
Noise Emissions:	84dB(A)@ 1 Meter Maximum Flow in Wide Fog

PRODUCT WARNINGS

- ⚠ WARNING:** Charge the unit slowly to facilitate a controlled water pressure build-up during start-up. Open and close slowly. Rapid opening will produce a sudden thrust. Rapid opening and closing can cause water hammer. Have your monitor properly supported to control the reaction force created by the stream.
- ⚠ WARNING:** At pressures below that indicated on the label, the nozzle will have reduced flow and reach. Be sure you have enough flow and pressure for the situation (See IFSTA and NFPA manuals for guidelines).
- ⚠ WARNING:** Ensure the nozzle is aimed in a direction that is safe, prior to flowing.
- ⚠ WARNING:** Ensure the thread on the nozzle swivel is matched to the thread on the monitor.

PRODUCT CAUTIONS

- ⚠ CAUTION:** If any tags or bands on the nozzle are worn or damaged and cannot be easily read, they should be replaced.
- ⚠ CAUTION:** For use with fresh water or standard firefighting foams only. Not recommended for use with salt water. After use with foam or salt water, flush with fresh water.
- ⚠ CAUTION:** For firefighting use only.
- ⚠ CAUTION:** Do not over tighten the nozzle onto the hose connection.
- ⚠ CAUTION:** The nozzle is configured for optimum performance. Do not alter in any manner.
- ⚠ CAUTION:** Do not expose to Trichlorethylene or Trichlorethane. These chemicals can weaken the parts and make the nozzle inoperable over time.

PHONE: 330.264.5678 or 800.228.1161 | FAX: 330.264.2944 or 800.531.7335

www.akronbrass.com



STYLE 5175 SELECTABLE GALLONAGE NOZZLE OPERATING INSTRUCTIONS

⚠ CAUTION: Your nozzle should be inspected prior and after each use, to ensure it is in good operating condition. Periodically, an unanticipated incident may occur where the nozzle is used in a manner that is inconsistent with standard operating practices and those listed in IFSTA. A partial list of potential misuses follows:

- Operating above maximum rated pressure and flow.
- Not draining, and allowing water to freeze inside the nozzle.
- Dropping the nozzle from a height where damage is incurred.
- Prolonged exposure to temperatures above +130 degrees F, or below -25 degrees F.
- Operating in a corrosive environment.
- Other misuse that might be unique to your specific fire fighting environment.

There are many “tell tale” signs that indicate nozzle repair is in order, such as:

- Controls that are either inoperable or difficult to operate.
- Excessive wear.
- Poor discharge performance.
- Water leaks.

If any of the above situations are encountered, the nozzle should be taken out of service and repaired, plus tested by qualified nozzle technicians, prior to placing it back in service.

OPERATING INSTRUCTIONS

Style 5175: Manual Override: Pull manual override knob out. Once out, rotate to the desired stream position. When finished, push and turn the override knob until it goes back into the stored position.

- The Style 5175 has an adjustable flow rate. To change the flow rate, shut off the flow then push the baffle head in and rotate until the desired setting aligns with the roll pin. Then adjust your engine to provide 100 psi (7 bar) at the inlet of the nozzle.

NOTE: Changing the flow setting without adjusting the pressure will affect your actual flow rate i.e. if you change to a higher flow setting, your inlet pressure will decrease and flow will be less than shown on the baffle head. If you change to a lower flow setting, your pressure will increase and your flow rate will be more than shown on the baffle head.

MAINTENANCE

- Under normal conditions, periodically flushing the nozzle with clean water and cleaning grit and dirt from around exterior moving parts will allow the nozzle to operate as designed.
- Over time the seals and turbine teeth may need to be replaced. This can be accomplished by purchasing the appropriate Akron repair parts. Use Qualified maintenance mechanics or return the nozzle to Akron Brass for repair.

WARRANTY AND DISCLAIMER: We warrant Akron Brass products for a period of five (5) years after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service.

We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty.

© Akron Brass Company. 2019 All rights reserved. No portion of this can be reproduced without the express written consent of Akron Brass Company.

PHONE: 330.264.5678 or 800.228.1161 | FAX: 330.264.2944 or 800.531.7335

www.akronbrass.com